

IMPORTANT

READ ALL!

RINSE WITH FRESH WATER AFTER EACH USE!!!

****Failure to rinse may make headphone defective due to salt corrosion****

DO NOT LEAVE OUT IN SUN

Store indoors

Do not charge when wet
(dry off first)

WARNING: Songs downloaded improperly may not play or may cause headphone controls to malfunction.

- Ensure each song is in the correct file format (see manual) and is downloaded correctly. Each song should be at least ~1mb (good indicator of a proper download)

