












<div><div>ROGUEWAVE</div><div>Bone Conduction Headphones</div><div>-- User Manual --</div></div> 	<div><div><div>Power Button/ Play Pause</div><div>Previous Song "-"</div><div>Volume Button "-"</div></div><div><div>Double click "+"</div><div>Single loop</div><div>Random play</div><div>Sequential play</div><div>Next Song "+"</div><div>Volume Button "+"</div></div><div><div>Battery Level Display</div><div>Charge Port/ Song Download</div><div>Mode Display</div><div>Microphone</div></div></div> 	<div><div>ON/OFF</div><div><div>Power ON:</div><div>Press and hold the Power Button for 2 seconds until the LCD Screen display Battery Level and MP3 mode with "power on" prompt sound</div></div><div><div>Power Off:</div><div>Press and hold the Power Button for 2 seconds until you hear the "power off" prompt sound</div></div></div> <div><div>Bluetooth Pairing</div><div>To enable Bluetooth for the first time, you need to manually click on the connection button of your device. The headphones prompt sound is: Bluetooth is connected.</div><div><div>1. In power on state, double-click the power button to switch the headphones to Bluetooth mode, the LCD screen will display Bluetooth mode and with "Bluetooth mode" prompt sound.</div><div>2. Open your device's Bluetooth settings and select "ROGUEWAVE" headphones will say connected.</div></div><div><div>NOTE:</div><div>In order to save power, we have set the headphones to automatically shut down after leaving the Bluetooth range for 30 minutes.</div></div></div>	<div><div>VOLUME CONTROL + -</div><div>The volume control has 1-16 sections, when the volume is at its highest, there will be a "maximum volume" sound reminder.</div><div><div>Volume Up:</div><div>In music or call mode, click the "+" button to increase the volume by one bar</div></div><div><div>Volume Down:</div><div>In music or call mode, click the "-" button to decrease the volume by one bar</div></div><div><div>Note:</div><div>Maxing out your phone's volume does not set the headphones to maximum. Use the '+' button on the headphone to increase the volume further</div></div><div><div>MULTIFUNCTION BUTTON</div><div><div>1. Play/Pause Music</div><div>Click once Power Button to play/pause</div></div><div><div>2. End Call</div><div>under call status, click once Power Button to end call</div></div><div><div>3. Answer Call</div><div>When in Bluetooth connection /music play, click once Power Button to answers the call when there is an incoming call</div></div><div><div>4. Reject Call</div><div>When in Bluetooth connection /music play, long press the Power Button for 2 seconds to reject call when there is an incoming call Button to end call</div></div><div><div>5. Previous Song</div><div>In music mode, press and hold the "-" button for 2 seconds to play the previous song</div></div><div><div>6. Next Song</div><div>In music mode, press and hold the "+" button for 2 seconds to play the next song previous song</div></div></div></div>	<div><div>7. Voice Assistant:</div><div>(After connecting bluetooth, In the state of not making a phone call) continuously click power button 3 times to enter voice mode, then click power button 3 times to exit; (Note: to start siri, android, you need to open the "bluetooth headphone button start" in the voice assistant, ios need to turn off the background to open the siri function).</div><div><div>8. Press any two buttons simultaneously in MP3 Mode to enter single song loop/random play/sequential play.</div></div><div><div>MP3 MODE</div><div>The system defaults to MP3 mode when each power on.</div><div><div>1. In MP3 mode, double click the power button to switch to Bluetooth mode, and the LCD screen will display Bluetooth mode and with "Bluetooth mode" prompt sound.</div><div>2. In Bluetooth mode, double click the power button to switch to MP3 mode, and the LCD screen will display MP3 mode and with "MP3 mode" prompt sound.</div><div>3. The MP3 function supports music in MP3, WAV, WMA, APE format.</div></div></div></div>
<div><div>ROGUEWAVE</div></div>	<div><div>HOW TO ADD MUSIC</div><div><div>Step 1: Plug in charger to laptop</div><div>Step 2: press on pop up folder called "ROGUEWAVE"</div><div>Step 3: drag downloaded mp3 music files into the folder</div></div><div><div>How to download music as an MP3</div></div><div><div>First option (free & fast)</div><div><div>1 Copy link of song from soundcloud</div><div>2 Past link into https://sclouddownloader.net/</div><div>3 Music is now in mp3 file, drag it into ROGUEWAVE folder</div></div></div><div><div>Second option:</div><div><div>1 Purchase songs on itunes store</div><div>2 Download as mp3 or as AAC</div><div>3 If AAC use https://cloudconvert.com/aac-to-mp3 or https://convertio.co/mp3-converter/ to make it MP3 format</div><div>4 Music is now in mp3 file, drag it into ROGUEWAVE folder</div></div></div><div><div>Third option:</div><div><div>1 Download free music from https://freemusicarchive.org/home or https://www.jamendo.com/start or other sources</div><div>2 If not already mp3 when downloaded use https://cloudconvert.com/aac-to-mp3 or https://convertio.co/mp3-converter/ to make it MP3 format</div><div>3 Music is now in mp3 file, drag it into ROGUEWAVE folder</div></div></div></div>	<div><div>CHARGING</div><div><div>1. When the headphones is charging with the 5V charging cradle, the headphones is turned off and will not be turned on, and the last digit of the percentage of the display is flashing.</div><div>2. When charging, the percentage [100%] means the charged amount is full.</div></div></div> <div><div>CHARGER AND BATTERY</div><div><div>1. Before using any charger to charge the headphones, please check whether the charger specifications are in line with the requirements(recommended charger output voltage DC5V +/-0.25V, output current: 100mA-500mA), charging voltage is too high may damage the headphones.</div><div>Warning: Only use approved chargers with this package, use of other chargers may result in danger. If the factory is shipped with a charging cable, you need to connect the charger or computer through the 3C certification to charge it. Prohibit serious collision with this product, serious impact may damage the electronic motherboard and battery.</div></div></div> <div><div>CHARGING THE BATTERY</div><div>The headphones use built-in non-removable rechargeable battery, please do not try to remove the battery from the headphones, so as not to damage the headphones. If a long term non-use headphones, please store it in a dry and ventilated place, and charge it every two months.</div></div> 	<div><div>1. When the headphones connected to show 10% or less, and hear the low battery notice please charge, that the headphones power is insufficient. if you continue to use it will automatically shut down, then you need to charge.</div><div>2. Plug the charger into the AC power outlet.</div><div><div>ADJUSTABLE STRAP (FIXED STRAP)</div><div>Function 1: Adjustable Strap to Make Fit More Secure</div><div>Function 2: Fixed Strap</div><div>When using the fixed strap can prevent headphones from falling off due to water flow impact</div><div>2 straps recommended. Use more or less based on tightness preference. Download or delete songs on your computer The computer is connected to the headset through the magnetic data cable, and the computer will display "Rogue Wave" folder after 5 seconds</div><div>The MP3 function supports music in MP3,WAV, WMA, APE format.</div></div></div>	<div><div>Tightness and comfort</div></div>